



COMMERCIAL SERIES LINEAR FLOODLIGHT

IMPORTANT NOTE:

- Luminaire must be installed and grounded in accordance with the National Electrical Code (NEC) and local codes.
- Luminaire is UL listed for above grade installation only.
- Always use UL recognized wire connectors for connections.

MAINTENANCE: To assure proper operation and efficiency, lens must be kept clean and free of dirt, dust, leaves, trash and mineral deposits from water. A regular scheduled maintenance program is recommended.

SAFETY WARNING: Luminaire can become hot. Take care when locating luminaires.

NOTE: Save these instructions for future reference.



LUMINAIRE MOUNTING (KNUCKLE) TO JUNCTION BOX(ES):

- 1. Make sure electrical supply is off at circuit breaker before starting luminaire installation or servicing luminaire.
- 2. Thread SS Knuckle Stem into Junction Box Lid. Tighten fully.
- Loosen the Knuckle Aiming Screw, rotate the Knuckle Stem to align with SS Knuckle Stem.
- 4. Route luminaire supply conductors into wet location rated J-Box (by others). Attach conduit supply conductors (by others) to the luminaire conductors observing polarity, line to black, neutral to white, and ground to green. Connect the supply / luminaire conductors using approved wiring methods.
- Secure the Junction Box Lid onto the Junction Box using the Junction Box Lid Screws. Tighten.
- Position the Knuckle Stem over the SS Knuckle Stem. Lock in place with Knuckle Set Screw(s).
- 7. Adjust the aim of the fixture and firmly re-tighten the Knuckle Aiming Screw(s).
- 8. Supply power to the luminaire and check for proper operation.



